

### **Installation instructions for Avalon wall mounted shower set with Brooklyn Fire taps**

#### Rough-in instructions:

Requires half inch male threaded connection point at 200mm below desired height of shower rose.  
For recommended shower rose height of 2m, install half inch male thread at 1800mm.

For cavity walls, install timber blocking minimum 45mm thick in the wall, on centre line of shower, between 500mm and 1m above FFL

For Brooklyn Fire taps, recess in-wall tap bodies 5-15mm back from finished wall.

#### Final fit-off.

The loose brass nut near the top of the shower pipe screws to the wall mounted male thread.

1. Trim the male thread in the wall to approx. 15mm long. This will allow room for the cover plate (supplied) and the loose nut on the shower pipe.
2. Using the loose brass nut, attach the shower pipe to the extended male thread. Keep the brass cap and kingco nut for the second fixing attached to the copper spigot on the shower pipe.
3. Holding the shower pipe in position and parallel to the wall, mark the location of the the brass cap on the wall.
4. Remove shower pipe, detach the kingco nut and brass cap and fix the brass cap to the wall using a thick gauge roofing screw. Note that the 12.7mm copper spigot which will sit inside the brass cap may need to be trimmed if it holds the shower too far off the wall.
5. Re-attach the shower to the male thread and the brass cap, tightening the kingco nut onto the brass cap, thus clamping the shower in position.
6. Install shower rose and test all connections